



1321 S VALLEY CENTER DRIVE  
BAY CITY, MI 48706  
(989) 686-0350 FAX# (989) 686-0399  
1-800-248-5060

## **OPERATING INSTRUCTIONS FOR THE K-50, H-75, or F-100 SANITIZING CABINET**

1. Acquire the keys taped to the top or bottom of cabinet.
2. Remove the ultraviolet lamp from the packing and insert it into the fixture.
3. Plug the unit into any regular 110 V with ground outlet.
4. Position eye glasses or goggles on the shelves. Always leave space between the items to allow the ultraviolet light to strike the entire item. Stacking items will render poor results.
5. Close the doors and set the timer as desired, 15 minutes for the maximum effect.
6. View the sight glasses to see that the cabinet and the bulb are working properly.

**NOTE: DO NOT USE A 3 WIRE ADAPTER ON THE POWER CORD ON THIS UNIT!**

**WARNING: NEVER LOOK AT AN OPERATING ULTRAVIOLET LAMP WITH UNPROTECTED EYES!**